



# User Manual

Model: H6630  
Govee Gaming Pixel Light



# IMPORTANT SAFETY INSTRUCTIONS

When using products, basic precautions should always be practiced including the following:

## READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- The light is not waterproof. Avoid exposing it to splashing or dripping water.
- The operating temperature should be within -10°C to 40°C (14°F to 104°F).
- The internal light source cannot be replaced. If it breaks, you must replace the entire light section.
- Do not install the light with a dimming driver.
- Avoid installing the light near heat sources.
- Avoid installing the light near potentially dangerous sources (e.g. candles, liquid-filled objects).
- Keep the speaker away from any magnets.
- CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.

## SAVE THESE INSTRUCTIONS

# Introduction

Thank you for choosing Govee Gaming Pixel Light!

This pixel light displays spotless and diffused square pixel style lighting effects, creating a splendid feast for the eyes.


Featuring rich software functions and strong DIY tools, Govee Pixel Light offers superior options when creating a variety of animations and curating a unique atmosphere.

# What You Get

Item	Quantity
Pixel Light	1
Desktop Stand	1
Wall Mount Bracket	1
Power Adapter	1
User Manual	1


## At a Glance

1. Power Button: Short press to turn on/off the screen
2. Volume Button: Short press to increase/decrease the volume and long press to mute.
3. Scene Carousel Mode: Press to set the Scene Carousel Mode, and press again to pause or continue.
4. Customized Shortcuts: Press to enter the set mode. Relevant functions can be set via Govee Home App.
5. Sound Pickup
6. Reset
7. Screw Holes




# Installing Your Device


1. Confirm the position with the provided desktop stands and wall mount brackets.
2. Mount on the wall: Insert two short screws into the holes on the back, use the expansion screw to fix the wall mount brackets, and then align the two screws to the position of the bracket.



(1)



(2)



(3)

3. Place on the desktop: Place the desktop stand in the middle of the light, trapping its bottom.
4. Connect the power adapter to the power supply and finish installation.

**Note:**

Before connecting to the app, the device, while connected to a power source, will automatically enter Standby Mode (with the indicator light off) if the screen is inactive for more than 10 minutes. Press any button to wake up the device and exit Standby Mode. After connecting to the app, Standby Mode will be disabled.

## Pairing Your Device with the Govee Home App

### What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- ① Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
- ② Turn on the Bluetooth in your smartphone.



- 3 Open the app, tap the "+" icon in the top right corner and search "H6630."
- 4 Tap the device icon and follow the on-screen instructions to complete pairing.

## Controlling the Device with Your Voice

1. Open the app, then tap the device icon to enter the control page.
2. Tap the settings icon in the top right corner.
3. Go to the app's Settings page and follow the instructions under "User Guide" to control the device.

## Specifications

Power Input (Adapter)	AC 100-240V AC (US Plug) AC 200-240V (EU & BS Plug)
Power Input (Control Box)	12VDC 1A
Light Displaying Technology	RGBIC
Pixel Lamp Bead Number	1024
Working Temperature	-10°C to 40°C (14°F to 104°F)

# Troubleshooting

1. Cannot connect to Govee Home App.
  - a. Check if the **light** is powered on.
  - b. Check if **Bluetooth** on the smartphone is enabled, or try connecting to another smartphone.
  - c. When connecting for the first time, ensure the smartphone is near the **light**.
  - d. If the connection error **still** exists, delete the connected **light** from the "Device" page on the app.
  - e. Reconnect to Govee Home App by **following** the previously provided instructions.
2. Wi-Fi disconnected or failed to connect.
  - a. Check if the **light** is powered on.
  - b. Do not skip the Wi-Fi connection steps during the **light** pairing process.
  - c. Ensure your Wi-Fi router is 2.4GHz. 5GHz is not supported.
  - d. Ensure you entered the correct Wi-Fi password during the Wi-Fi setup process.
  - e. Try using another smartphone to pair with the **light** to ensure your network is working properly.
  - f. Shorten the distance between the **light** and the Wi-Fi router to **less than 50 inches**, then reconnect.
3. Cannot connect to Alexa or Google Assistant.
  - a. Ensure the Wi-Fi connection is stable and working properly.
  - b. Go to the app's Settings page and **follow** the instructions under "User Guide" to pair the **light** again.
4. The data display or transmission of the pixel **light** is too slow.
  - a. Keep the router as **close** to the pixel **light** as possible to ensure that the network transmission remains normal.

# Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: [support@govee.com](mailto:support@govee.com)

 Official Website: [www.govee.com](http://www.govee.com)

 @GOVEE    @goveeofficial    @govee.official

 @GoveeOfficial    @GOVEE



Govee Home App

For FAQs and more information,  
please visit: [www.govee.com](http://www.govee.com)