



User Manual

Model: H8048

Govee Smart Gaming Light Bars Pro

Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS When using products, basic precautions should always be practiced including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- The light is not waterproof. Avoid exposing it to splashing or dripping water.
- The operating temperature should be within -10 °C to 40 °C (14°F to 104°F).
- The internal light source cannot be replaced. If it breaks, you must replace the entire light section.
- Do not allow children to install the light alone.
- Do not install the light with a dimming driver.
- Avoid installing the light near heat sources.
- Avoid installing the light near potentially dangerous sources (e.g. candles, liquid-filled objects).
- This product is equipped with a microphone, which is only used to capture the rhythm of the sound.

CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.

SAVE THESE INSTRUCTIONS

Introduction

Thank you for choosing Govee Smart Gaming Light Bars Pro! This product provides you with vivid and immersive RGBIC ambient lighting effects for your gaming desktop. With its unique cyberpunk appearance and three-sided illumination area (front, back, and base), your gaming lighting gets upgraded to a new level. Integrated with your desktop devices via smart control, this light bar


supports Alexa, Google Assistant, Razer Chroma, Matter, and Govee Desktop for lighting effect synchronization. Tap to start your adventure in the gaming world now!

What You Get

Item	Quantity
Light Bar	2
Control Box	1
Power Adapter	1
Cleaning Cloth	1
User Manual	1
Service Card	1


At a Glance

Light Bar :



02

Control Box:



Control Box

On/Off Button	Press to turn On/Off.
Color Button	Press to adjust the color.
Music/Dimmer Button	Press to enter Music mode. Long press to adjust the brightness.
Indicator Light	a. A red light indicates the device is not connected to the network. b. A blue light indicates the device has successfully connected to the network. c. No light indicates that the device is not powered on or might be broken.

Pairing Your Device with Govee Home App

What you need:

- A Wi-Fi router supporting 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
1. Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
 2. Turn on Bluetooth on your smartphone.



3. Open the app, tap the "+" icon in the top right corner and search "H8048".
4. Tap the device icon and follow the on-screen instructions to complete pairing.


Controlling the Device with Your Voice

1. Open the app, then tap the device icon to enter the details page.
2. Tap the settings icon in the top right corner.
3. Select User Guide and follow the on-screen instructions to control the device using your voice.

Specifications

Power Input (Adapter)	AC 100-240V AC (US Plug) AC 220-240V (EU & BS Plug)
Power Input (Control Box)	12VDC 2A
Light Displaying Technology	RGBIC
Control Methods	App, Control Box, Voice Control
Working Temperature	-10°to 40°C (14°to 104°F)

Disassembly Tip



The product is divided into two parts: (1) a light source and (2) an adapter. By detaching the output terminal of the adapter, you can easily remove the light source or the adapter.

Troubleshooting

1. Cannot connect to Govee Home App.
 - a. Check if the light is powered on.
 - b. Check if Bluetooth on the smartphone is enabled, or try connecting to another smartphone.
 - c. When connecting for the first time, ensure the smartphone is near the light.
 - d. If the connection error still persists, please delete the connected light from the "Device" page on the app. Reconnect to Govee Home App by following the previously provided instructions.
2. Wi-Fi disconnected or failed to connect.
 - a. Check if the light panel is powered on.
 - b. Do not skip the Wi-Fi connection steps during the device pairing process.
 - c. Ensure your Wi-Fi router is 2.4GHz. 5GHz is not supported.
 - d. Ensure you entered the correct Wi-Fi password during the Wi-Fi setup process.
 - e. Try using another smartphone to pair with the panel lights to ensure your network is working properly.
 - f. Shorten the distance between the light and the Wi-Fi router to less than 50 inches, then reconnect.
3. Cannot connect to Alexa or Google Assistant.
 - a. Ensure the Wi-Fi connection is stable and working properly.
 - b. Go to "User Guide" on the "Settings" page to pair the panel lights again.

Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @GOVEE  @goveeofficial  @govee.official

 @GoveeOfficial  @GOVEE



Govee Home App

For FAQs and more information,
please visit: www.govee.com