



# User Manual



Model: H7086

Govee Outdoor Garden Lights

# IMPORTANT SAFETY INSTRUCTIONS

When using products, basic precautions should always be practiced including the following:

## READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- Caution - the power adapter should be placed indoors or connected into a socket with an IP67 protective enclosure.
- Do not allow children to assemble and install this product without adult supervision.
- Avoid installing this product near major heat sources.
- External dimmers cannot be used with this product.
- Use this product with the provided power adapter only.
- The internal lighting source cannot be replaced separately, and if you have to replace the whole lamp structure, please get in touch with customer service for professional after-sale services.
- CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.
- Any open ends must be sealed-off before use.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- To reduce the risk of strangulation, the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.
- Do not remove or insert lamps while the lamps is connected to the supply.
- Do not connect the lamps to the supply while it is in the packaging.
- The light source or separate control gear is not intended for use in other applications.
- For ambiance lighting only. Not for illumination.

- The control box of this product contains a microphone that is used to detect the rhythm changes of music and sound, to achieve music lighting effects.

## SAVE THESE INSTRUCTIONS



### Introduction

Thanks for choosing Govee Outdoor Garden Lights. Based on the layout of your garden, you can customize the height and orientation of the lights, and easily fix them with provided ground stakes. It has multiple preset scene modes, bringing pleasant lighting to your yards. In addition, the built-in mic inside the control box also enables the synchronization of light and sound.


### What You Get

Item	Quantity
Lamp A	2
Lamp B	2
Lamp Pole	4
Lamp Base	2
Ground Stake	2
Accessories Package	1
Power Adapter	1
Control Box & Connecting Wire	1
User Manual	1

# At a Glance




The product is divided into two parts: (1) a light source and (2) an adapter. By detaching the output terminal of the adapter, you can easily remove the light source or the adapter.



## Accessories Package






Completed installation diagram

## Installing Your Device


- Before installing, confirm the lights are working properly by attaching the garden lights together, connecting them to the control box and power adapter, and plugging them into a power source. Once confirmed, unplug, disassemble, and prepare the lights for installation.



Materials in the package can be used to install two garden lights, with two optional heights.

**Tips:**

- a. A garden light can be installed with up to three lamp poles.
- b. Lamp B can also be installed between the poles.




## Step 1: Assemble Garden Lights

Complete the assembly from lamps A and B to a lamp pole and base by referring to the sequence shown in the picture below.


### Tips:

- When the input wires of lamps A and B pass through the lamp pole, stagger the two connectors one front and one back to prevent them from getting stuck in the inner wall of the lamp pole.
- Fix with screw A after splicing one section.
- Lamp B can be installed in any direction.



## Step 2: Install Ground Stake

Place the input wire in the wiring channel of the base, secure the ground stake under the lamp base using screw B.




### Step 3: Install Garden Lights


1. Connect two assembled garden lights to the control box output wire, and tighten the waterproof caps.
2. Put two garden lights in place (the power cable length between them is 2 meters).

**Note:**


a. when installing garden lights, please hold the lamp pole and insert the ground stake into the soil. Do not hold and push the lamps on both ends.



b. If installing in hard soil, you can remove the top cover, hammer the garden light vertically into the ground, and then cover it back.



3. Connect the power cord at the front end of the control box to the power adapter and tighten the waterproof caps. Power on to start using the garden lights.



## Pairing Your Device with Govee Home App

### What you need:

- A Wi-Fi router supporting 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.

1. Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
2. Turn on Bluetooth on your smartphone.



3. Open the app, tap the "+" icon in the top right corner and search "H7086".

4. Tap the device icon and follow the on-screen instructions to complete pairing.

## Specifications

Power Input	200-240VAC 50/60Hz
Power Output	24VDC 1.5A
Color Rendering Index	CRI > 90
Color Temperature	2700K - 6500K
Light Color	RGBWW
Waterproof Rating	Control Box (IP67) Garden Lights (IP66)

## Troubleshooting

### 1. Fails to connect to Wi-Fi.

- Make sure the distance between the device and the router is less than 100ft.
- Keep as few obstructions (e.g. walls, windows) as possible between the device and the router.
- Make sure the Wi-Fi name and the password you entered are correct.
- Make sure the Wi-Fi you connect to is 2.4GHz. 5GHz is not supported.

### 2. Lost Wi-Fi connection or cannot use the device with the app.

- a. Make sure your home Wi-Fi works well.
- b. Check whether the Wi-Fi password has been modified.
- c. Keep as few obstructions (e.g. walls, windows) as possible between the device and the router.
- d. Check whether the device has been connected to Wi-Fi. If not, please re-connect the device to Wi-Fi as mentioned above.

### **3. Cannot pair or connect with Alexa or Google Assistant.**

- a. Ensure the stability of the Wi-Fi connection.
- b. Go to the app's Settings page and follow the instructions under "User Guide" to pair the device again.

### **4. The synchronization effect for Music Mode does not work properly.**

- a. Ensure the control box is close to the music source to ensure better sound pickup.

### **5. Can multiple users control one device?**

- a. Each device can only be controlled by one account.
- b. If multiple users want to control the same device, ensure they are using the same account.

## **Matter Guide**

### **Cautions:**

1. You need to complete the network connection of apps that support Matter (e.g. Google Home/Apple HomeKit etc.) within 15 minutes after the product is powered on when using Matter for the first time.
2. An IPv6 network is required.

3. Changing the network may cause Matter to malfunction.
4. If unable to connect successfully, please reset the network settings on the Wi-Fi setup page and try again.

### **Step 1**

Find the QR code or device number of Matter on the product or on Device Settings page in Govee Home App.

### **Step 2**

Turn on the Bluetooth on your smartphone.

### **Step 3**

Download and open the app that supports Matter like Google Home/Apple HomeKit, etc.

### **Step 4**

Use the device number or QR code on the product in the app to complete the network connection of Matter for the product.

## **Customer Service**

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: [support@govee.com](mailto:support@govee.com)

 Official Website: [www.govee.com](http://www.govee.com)

 @GOVEE    @goveeofficial    @govee.official

 @GoveeOfficial    @GOVEE



**Govee Home App**

For FAQs and more information,  
please visit: [www.govee.com](http://www.govee.com)