



User Manual

Model: H61D5

Govee Neon Rope Light 2

Safety Instructions

Read and follow the safety instructions below:

- This device is for indoor use only.
- Avoid dropping the device from high places.
- Do not significantly modify the device.
- Do not leave children unattended with the device.
- Use the product with the provided power adapter only.
- Although this product has good bending performance, when bending the neon rope light, please try not to fix the clip too close and bend it too much, so as not to damage the light beads and then affect the life span.
- If you want to get the maximum adhesion, it is suggested that you wait for a period of time to install the neon rope light after fixing the clip.

Introduction


Thanks for choosing the Govee Neon Rope Light 2. The soft silicone material makes it suitable for creating DIY shapes. It supports RGBIC light technology, Matter, and smart voice control systems such as Alexa and Google Assistant, allowing you to control wonderful lighting effects from your phone.

What You Get

Neon Rope Light	1
Adapter	1
User Manual	1

At a Glance


- A. Turn the light on/off.
- B. Short press to change colors. The color of the button can be set in the app.
- C. Short press to adjust the brightness.



Installing Your Device

Before You Install

1. Unpack the box and check **all** items listed in the packing list.
2. Power on the neon rope light and check whether it **lights up**.
3. Plan the shape you want in advance. You can **also** log in to your Govee Home account to add the device and check the recommended shapes.
4. If you need to use the bend clip while installing, make sure the longer side of the bend clip is at the inner corner.



Installing Steps

- 1 Wipe the surface to make sure it's clean and dry.




- 2 After tearing off the adhesive film, you can stick the clip to the place you want and press it firmly (if necessary, you can reinforce the clip with a screw), and then clip the neon rope light into the clip.



- 3 Peel off the protective film on the control box and stick it on. Place the control box close to the music source to achieve the best music effect.



- 4 Power on the neon rope light and start using.



Pairing Your Device with Govee Home App

What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11b/g/n bands. 5GHz is not supported.
- 1 Download Govee Home App from the App Store (iOS) or Google Play (Android). Log in with your account. New users need to create an account.
 - 2 Turn on your smartphone's Bluetooth.
 - 3 Open the app, tap the "+" icon in the top right corner and search "H61D5."
 - 4 Tap the device icon and follow the on-screen instructions to complete pairing.



Matter Guide

Cautions:

1. You need to complete the network connection of apps that support Matter (e.g. Google Home/Apple HomeKit, etc.) within 15 minutes after the product is powered on when using Matter for the first time.
2. An IPv6 network is required.
3. Changing the network may cause Matter to malfunction.
4. If the product cannot connect to the app, long press the power button of the product and press the second button for 4 times consecutively to restore factory settings. After that, try connecting again later.

Step 1

Find the QR code or device number of Matter on the product or on the "Device Settings" page in Govee Home App.

Step 2

Turn on the Bluetooth on your smartphone.

Step 3

Download and open the app that supports Matter like Google Home, Apple HomeKit, etc.

Step 4

Use the device number or QR code on the product in the app to complete the network connection of Matter for the product.

Specifications

Model	H61D5
Adapter Input	AC 100-240V
Light Input	24VDC 2A
Light Displaying Technology	RGBIC
Control Methods	Govee Home App, Voice Control

Troubleshooting

- ❶ Cannot connect to Govee Home App.
 - Check if the device is powered on.
 - Check if the smartphone's Bluetooth is enabled, or try connecting with another smartphone.
 - When connecting for the first time, make sure the smartphone is near the device.
 - If a connection error still exists, delete the connected device from the "Device" page on the app.
 - Reconnect to Govee Home App by following the previously provided instructions.
- ❷ No response to any press during use.
 - Use a needle or a similar object to press into the hole on the bottom of the device to reset it.

This product contains a light source of energy efficiency class G. Colour - tuneable light sources that can be set to at least the colours listed in this point and which have for each of these colours, measured at the dominant wavelength, a minimum excitation purity of:

Blue	465.3nm	97.5%
Green	521.3nm	76.6%
Red	623.7nm	100.0%

and are intended for use in applications requiring high-quality coloured light.

Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @Govee  @govee_official  @govee.official

 @Goveeofficial  @Govee.smarthome



Govee Home App

For FAQs and more information,
please visit: www.govee.com