



User Manual

Model: H6056
Govee RGBICWW Light Bar

IMPORTANT SAFETY INSTRUCTIONS

When using products, basic precautions should always be practiced including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- The light bars are not waterproof. Avoid exposing them to splashes or drops of water.
- The operating temperature should be between -10° to 40 °C (14° to 104°F).
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- Do not allow children to install the light bars alone.
- Avoid installing the light bars near heat sources.
- External dimmers cannot be used with the light bars.
- Avoid installing the light bars near potentially dangerous sources (e.g., candles, liquid-filled objects).
- DO NOT ATTEMPT TO OPEN, MODIFY, OR REPAIR THIS PRODUCT. Any alteration or use of non-approved parts voids all warranties, negates compliance certifications, and may result in malfunction, electric shock, fire, or personal injury.
- Do not cover the product with flammable materials such as cloth or paper to prevent fire accidents.
- Please do not operate the product with wet hands or pull on the power cord, as this may damage the power cord and cause a fire or electric shock.
- When the product is not in use for a long period of time, please unplug the power cord from the outlet to prevent fire accidents.
- Regularly inspect the cable, power supply, and all other components. Do not use this product if any component is damaged.
- This product is intended for indoor use (ambient temperature: 25°C). Do not use it in damp locations such as bathrooms or outdoors. This product is not waterproof, and improper use may result in poor insulation, leading to electric shock.
- When cleaning the light fixture, please turn off the power supply, use a soft cloth dipped in neutral detergent, wring it out, wipe the fixture, and then wipe it dry with a dry cloth.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the whole luminaire shall be replaced.

- The control gear of this luminaire is a non-replaceable component; when the control gear reaches its end of life the whole luminaire shall be replaced.
- The control gear of this luminaire is a non-serviceable component, do not attempt to gain access to the control gear.
- The output ports of the control gear are for designated devices only. Do not connect other devices. Please follow the installation instructions provided in the manual.
- For ambiance lighting only. Not for illumination.
- The light source or separate control gear is not intended for use in other applications.
- To reduce the risk of strangulation, the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.
- The control box of this product contains a microphone that is used to detect the rhythm changes of music and sound, to achieve music lighting effects.
- Use this product with the provided power adapter only.
- Read and follow all instructions that are on the product or provided with the product.

SAVE THESE INSTRUCTIONS


Introduction

Thank you for choosing the Govee RGBICWW Light Bar. Govee RGBICWW Light Bar provides vibrant, ambient light, ideal for TV and PC screens. Our smart sound technology can perfectly synchronize sounds emitted from video games or movies to your lights, significantly enriching your visual experience.

What You Get


Light Bar	2
Control Box	1
Adapter	1
Table Mounting Bracket	2
Screen Mounting Bracket	2
User Manual	1
Service Card	1

At a Glance



Control Box

On/Off Button	Press to turn On/Off.
Color Button	Press to adjust the color.
Music/Dimmer Button	Press to enter Music mode. Long press to adjust the brightness.
Indicator Light	a. A red light indicates the device is not connected to the network; b. A blue light indicates the device has successfully connected to the network. c. No light indicates the device is not powered on or might be broken.



Light Bar





Table Mounting Bracket




Screen Mounting Bracket

Installing Your Device

- 1 Place the light bars on both sides of the table or mount them to the rear of your TV screen with the mounting bracket.



- 2 Connect the light bar cable to the control box.
- 3 Power on the adapter and connect it to the control box.
- 4 Installation completed!



Pairing Your Device with the Govee Home App

What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11b/g/n bands. 5GHz is not supported.
- 1 Download the Govee Home app from the App Store (iOS devices) or Google Play (Android devices).
 - 2 Turn on the Bluetooth in your smartphone.
 - 3 Open the app, tap “+” icon in the top right corner and search “H6056”.
 - 4 Tap the device icon and follow the onscreen instructions to complete pairing.



The Apple logo is a trademark of Apple Inc., registered in the U.S. and other countries and regions. Apple Store is a service mark of Apple Inc., registered in the U.S. and other countries and regions.



Google Play is a trademark of Google LLC.

Specifications

Power Input (Adapter)	100-240V \sim , 0.8A Max 50/60Hz (US Plug) 200-240V \sim 50/60Hz 0.4A (EU&BS Plug)
Power Input (Control Box)	12V --- 1.5A
Light Color	RGBICWW
Working Temperature	-10° to 40°C (14° to 104°F)

Matter Guide

Cautions:

1. You need to complete the network connection of apps that support Matter (e.g. Google Home/Apple HomeKit etc.) within 15 minutes after the product is powered on when using Matter for the first time.
2. An IPv6 network is required.
3. Changing the network may cause Matter to malfunction.
4. If the product cannot connect to the app, long press the power button of the product and click the second button for 4 times consecutively to restore factory settings. After that, try connecting again later.

Step 1

Find the QR code or device number of Matter on the product or on Device Settings page in Govee Home App.

Step 2

Turn on the Bluetooth on your smartphone.

Step 3

Download and open the app that supports Matter like Google Home /Apple Homekit, etc.

Step 4

Use the device number or QR code on the product in the app to complete the network connection of Matter for the product.

Troubleshooting

❶ Cannot connect the device to the Govee Home app?

- Ensure the device is powered on.
- Check if the Bluetooth on your smartphone is enabled or try connecting with another smartphone.
- When connecting for the first time, ensure your smartphone is close to the device.
- If you're still experiencing a connection error, delete the connected device from the "My Device" page on the app. Then, reconnect to the Govee Home app, following the instructions provided previously.

❷ The device lost connection?

- Ensure the device is powered on.
- Shorten the distance between the device and the router to less than 50ft/15m, then reconnect.
- If the device continues to lose connection, delete the connected device from the 'My Device' page on the app. Then, reconnect to the Govee Home app, following the instructions provided previously.

❸ The synchronization effect for Music mode does not work properly.

- Ensure the control box is close to the music source, which will help the mic pick up sounds better.

❹ Can multiple users control one device?

- Each device can only be controlled by one account.
- If multiple users want to control the same device, ensure that they are all using the same account.

Customer Service

🛠️ Warranty: 12-Month Limited Warranty

🔧 Support: Lifetime Technical Support


✉️ Email: support@govee.com

🌐 Official Website: www.govee.com

📺 @GOVEE 📷 @goveeofficial 🎵 @govee.official

✂️ @GoveeOfficial 📱 @GOVEE

Disassembly Tip



The product is divided into two parts: (1) a light source and (2) an adapter. By detaching the output terminal of the adapter, you can easily remove the light source or the adapter.



Govee Home App

For FAQs and more information,
please visit: www.govee.com