



# User Manual

Model: H60C1  
Govee Pendant Light

# IMPORTANT SAFETY INSTRUCTIONS

When using products, basic precautions should always be practiced including the following:

### READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- To prevent possible shock, turn off the main power at the circuit breaker before installing or fixing the device.
- All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, please consult a qualified electrician.
- For indoor use only. This product is not waterproof. Do not expose it to areas susceptible to water splashes or water drops.
- The internal light sources cannot be replaced. If the light sources sustain damage, the product should be replaced.
- Do not disassemble or modify the device and its accessories.
- Avoid installing this product near potentially dangerous heat sources or major heat sources (e.g., candles, liquid-filled objects).
- The working temperature should be between 14 to 77°F (-10 to 25°C). Store the product in places where the temperature is between -4 to 140°F (-20 to 60°C) if you do not plan to use it for a long time.
- External dimmer cannot be used with this product.
- Only use the control provided with or specified by these instructions to control this lamp.
- This lamp will not operate properly when connected to a standard (incandescent) dimmer or dimming control.
- CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.

### SAVE THESE INSTRUCTIONS

# Introduction


Thanks for choosing Govee Pendant Light! This pendant light supports RGBICWW three-segment color control, applicable to your dining room and kitchen island. With Govee Home App, you can set your desired color, brightness, and color temperature. The versatile scene modes and music modes await exploration.

## What You Get

Item	Quantity
Pendant Light	1
Accessory Kit	1
User Manual	1

# At a Glance

1. Pendant Light
2. Power Cord (Length adjustable)
3. Base
4. Installation Support
5. Power Supply
6. Zero Wire (White/Blue)
7. Fire Wire (Black/Brown)
8. Ground Wire (Yellow-Green Stripe)
9. Safety Cable



# Pairing Your Device with Govee Home App

## What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11b/g/n bands. 5GHz is not supported.



1. Download Govee Home App from the App Store (iOS) or Google Play (Android). Log in with your account. New users need to create an account.
2. Turn on your smartphone's Bluetooth.
3. Open the app, tap the "+" icon in the top right corner and search "H60C1".
4. Tap the device icon and follow the on-screen instructions to complete pairing.

# Matter Guide

## Cautions :

1. You will need to complete the network connection of apps that support Matter (e.g. Google Home/Apple HomeKit, etc.) within 15 minutes after the product is powered on when using Matter for the first time.
2. An IPv6 network is required.
3. Changing the network may cause Matter to malfunction.
4. If the product cannot connect to the app, switch the product off within 5 seconds of turning it on, then wait 5 seconds and switch the product back on. Repeat four times. You should see the warm and cool light flashing, this indicates that the device has been restored to factory settings.

## Step 1

Find the Matter QR code or device number on the product or on the “Device Settings” page in Govee Home App.

## Step 2

Turn on Bluetooth on your smartphone.

## Step 3

Download and open an app that supports Matter like Google Home, Apple HomeKit, etc.

## Step 4

Use the device number or QR code located on the product or in the app to complete the network connection for the product for Matter.

# Specifications

Model	H60C1
Input	AC 200-240V
Power	21W
Light Displaying Technology	RGBICWW
Lumens	1300lm@2700K
Color Temperature	2700K-6500K
Current	95mA

## Troubleshooting

- 1. Cannot connect to Govee Home App.**
  - a. Check if the device is powered on.
  - b. Check if the smartphone's Bluetooth is enabled, or try connecting to another smartphone.
  - c. When connecting for the first time, make sure the smartphone is near the device.
  - d. If the connection error still exists, delete the connected device from the "Devices" page on the app. Reconnect to Govee Home App by following the previously provided instructions.
- 2. Wi-Fi disconnected or failed to connect?**
  - a. Ensure your Wi-Fi router is 2.4GHz. 5GHz is not supported.
  - b. Ensure you entered the correct Wi-Fi password during the Wi-Fi setup process.
  - c. Try using another smartphone to pair with the device to ensure your network is working properly.
  - d. Shorten the distance between the device and the Wi-Fi router to less than 50ft, and then reconnect.

### **3. Cannot connect to Alexa or Google Assistant.**

- a. Ensure the Wi-Fi connection is stable and working properly.
- b. Go to “User Guide” on the “Settings” page to pair the device again.

### **4. Can multiple app users control the same app?**

- a. Each lamp can only be controlled by one account.
- b. If multiple users want to manage the same lamp, ensure they all use the same account.

# Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: [support@govee.com](mailto:support@govee.com)

 Official Website: [www.govee.com](http://www.govee.com)

 @GOVEE    @goveeofficial    @govee.official

 @GoveeOfficial    @GOVEE



**Govee Home App**

For FAQs and more information,  
please visit: [www.govee.com](http://www.govee.com)